





# STIHL®

## 4241 007 1003


0457 364 0031 C L17




1




2



3




4



002BB066 KN




**5**



**BG 45**  
**BG 46**  
**BG 55**  
**BG 65**  
**BG 85**  
**SH 55**  
**SH 85**

**6**



**BG 56**    **SH 56**  
**BG 66**    **SH 86**  
**BG 86**    **SHE 71**  
**BGE 61**   **SHE 81**  
**BGE 71**  
**BGE 81**

**7**

